

MultiDesks

E280 & E270 Product Manual



CE




 rifton®

Contents

Warnings and important information	3
Check your order	4
Recommended use	5
Item dimensions	5
Basic MultiDesks	
Non-tilt MultiDesk	6
Tilt MultiDesk	6
Operation	7
Accessories	
Set of snap-on-edges	8
Book box	9
Materials	10
Maintenance	11
Cleaning	11
User modifications	11

Key for EU users

Use this key to determine which sections of this product manual apply to you.

-  **Technical Users** For professionals who order and set up Rifton products.
-  **Home Users** For care-givers who use Rifton products on a regular basis.
-  **Maintenance Personnel** For anyone who is responsible for service or re-ordering of Rifton products and parts.

WARNINGS

- Thoroughly read and understand the information in this product manual before attempting to use this product. If the procedures and instructions in this product manual are not followed, serious injury could occur.
- A qualified professional must assess the appropriateness and safety of all equipment for each user.
- Correct use of this product requires the prior approval and ongoing guidance of a qualified therapist or physician.
- This product is intended for use by children of immature judgment. Adult supervision is required at all times.
- Do not use this product on rough and uneven terrain, around swimming pools, or near stairways.
- All mobility equipment may become unstable when used improperly.
- Straps and supports are provided for the safety of the user and must be carefully adjusted for comfort and security. The use of straps and supports must be supervised at all times.
- Restraints – Using straps, trays or supports to restrict a child's movement is considered behavioral restraint, which may raise ethical and legal issues for your facility. Rifton Equipment is not intended for this use.
- Do not sit, stand or climb on desk.
- This desk will be unstable if the legs are not installed according to directions.
- The desk top should be empty when making adjustments to the desk legs.

IMPORTANT

- Please save this product manual. Additional copies are available at www.rifton.com
- Please refer to the Rifton product catalog for our full warranty, or visit www.rifton.com

Check your order

Your Multidesk has been shipped according to your specifications. It will require some tool-free assembly. Follow these instructions to ensure that your MultiDesk is put together and used correctly. This product manual is comprehensive and may discuss features not included on your MultiDesk.

If your shipment is incomplete or in any way damaged on arrival, please call Customer Service, 800.571.8198.



CAUTION


- For indoor use only. The MultiDesk and accessories are not waterproof.

Recommended use

MultiDesks take the place of normal school desks for a child or adult who needs added support or better positioning of the work surface. These versatile desks come in 4 models and 3 heights so that the right desk can be found for each person with special needs.


Item dimensions

Leg height ranges* – Inches (cm)



*Note: Tilt-top adds 2" to height.

Table Dimensions – Inches (cm)



Basic MultiDesks

Non-tilt MultiDesk

Assembly

1. Screw all four legs in to MultiDesk tightly.
2. Set MultiDesk upright.

If MultiDesk wobbles, check that the legs are screwed tightly into the cones and adjusted to equal height.



Non-tilt MultiDesk

Tilt MultiDesk

Assembly

1. Lift tilt top and position curved stays in the holes in the sub top.
2. Lift top slightly to release child-proof safety-mechanism.
3. Locate yellow latch-release handle under MultiDesk top, and pull it out (see Figure 7b).
4. Lower top carefully to desired angle and let go of latch.
5. Check that tilt top is locked into position before letting go of it.



Tilt MultiDesk

Operation

Leg height adjustment of all MultiDesk models:

To adjust MultiDesk to a higher position, pull wooden leg out to desired height.

To lower MultiDesk height, lift the desk and push the yellow adjustment ring (A) down. Holding the ring down, push wooden leg (B) up until it locks at the desired leg height (see Figure 7a).




Figure 7a

Angle adjustment of all tilt MultiDesk models:

To change the angle of the tilt, lift tilt top slightly, pull yellow latch (C) located under front of MultiDesk, adjust tilt to desired position and release latch. Be sure latch engages properly before releasing tilt top (see Figure 7b).

For storage, curved stays (D) can be pulled all the way out of MultiDesk table holes and folded under tilt top (see Figure 7c).



Figure 7b



Figure 7c

Accessories

Set of snap-on edges

Recommended use

The set of snap-on edges (see Figure 8a) can be used to help keep things on the desk and to clamp a sheet of paper onto the table top.

WARNINGS

This accessory is intended for use on the following Rifton Equipment products only:

- E270 Small MultiDesk
- E280 Large MultiDesk

Operation

To attach the snap-on edges onto table top (see Figure 8b), take one of the shorter pieces and position it in the center of the side edge. Push the two clips (A) snugly against the desk until they snap in. Repeat for the other two pieces on the side and top.

To remove the snap-on edges, release clip tension under table top.



Figure 8a




Figure 8b

Book box

Installation

1. Unscrew one leg from the side of the MultiDesk where book box is going to be positioned.
2. Place book box with plastic lip (A) going over MultiDesk table surface top edge and the wooden cleat (B) underneath (see Figure 9b).
3. Slide book box so that curved indent is against the leg that is still in place.
4. Screw the removed leg tightly back into MultiDesk cone.
5. Check that MultiDesk does not wobble.



Figure 9a




Figure 9b

Materials ¶

- Steel hardware items (nuts, bolts, screws, etc) are typically zinc or nickel plated, or stainless steel.
- Upholstery items (pads, support blocks, padded prompts, etc) are typically fire-retardant polyurethane foam with a fire-retardant cover made from expanded polyurethane.
- Frames are typically steel or aluminum tubing, welded together, and coated with a baked-on paint finish. Some frame components may also be stainless steel.
- Tires are tubeless, filled with polyurethane foam, and do not require inflation.
- Straps are typically made of polypropylene or nylon webbing.
- Wooden components are typically birch plywood, solid maple, or laminated hardwood veneers, finished with a clear polyurethane lacquer.
- Tabletops are typically high-pressure laminate (Formica).
- Plastic components are typically injection molded from a variety of industrial resins.

All materials are latex, lead and phthalates free.

Maintenance 🧰

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

Cleaning 🧑 🏠 🧰

Wash the MultiDesk surface with mild detergent and warm water, using a soft cloth. Rinse with warm water, and dry with a soft cloth.

For more stubborn spots, use an all-purpose household cleaner such as Formula 409®, Windex® or Lestoil®. Follow manufacturers' directions.

For even more stubborn spots, use mild Lava® soap and rub gently.

Stains may be removed with undiluted Clorox® (protect your skin), by letting this bleach stand NO MORE THAN 1½ MINUTES. Rinse thoroughly with warm water. Repeat if necessary.

To clean the book box, wipe with a moist rag and mild detergent. Excessive water can damage the finish.

User modifications 🧑 🏠 🧰

We recognize that some clients may benefit from modifications made in the field. However, we cannot be responsible for customer modifications to our products without our supervision, testing, and evaluation.

Rifton Contact Info



Online

www.Rifton.com
Sales@Rifton.com



Phone

800.571.8198
9-5 EST



Mail

Rifton Equipment
PO Box 260
Rifton NY 12471-0260



Fax

800.865.4674

To order replacement parts

1. Locate the serial number of the product on the small white label.
2. Have this number available when you call **800.571.8198** for your customer service representative.

Use only replacement parts supplied by Rifton Equipment.

LC84 ECO N/A Revision H