Compass Chair dimensions

| User dimensions (inches) | R310 size 1 | R320 size 2 | R330 size 3 | R340 size 4 | R350 size 5 |
|---------------------------------|--|-------------|-------------|-------------|-------------|
| Height | 36 – 45 | 43-50 | 48-57 | 55-65 | 65+ |
| Knee to heel | With short legs: $9-11$ With standard legs: $10-13$ | 10½-14½ | 12½ –16½ | 14½-18½ | 161/2-201/2 |
| Min-max thigh circumference for | 101/2-231/2 | 12-281/2 | 141/2-301/2 | 15-341/2 | 171/2-381/2 |
| • | | | | | |



Key user dimension: height / knee to heel

The user's overall height and measurement from knee to heel is a general guide to help you select the appropriate chair. Choose the model that allows for growth.

Important: Make sure that seat width, depth and height are adequate for each user, and that the user's weight does not exceed the maximum working load.

| Item dimensions (inches) | R310 | R320 | R330 | R340 | R350 |
|-------------------------------|-------|-------------|-------------|-------------|-------------|
| Seat height—in 1" increments | 9-13 | 101/2-141/2 | 121/2-161/2 | 141/2-181/2 | 161/2-201/2 |
| Seat depth | 91/2 | 11 | 123/4 | 143/4 | 16½ |
| Seat width | 101/2 | 121/4 | 14 | 161/4 | 181/4 |
| Backrest height | 91/2 | 11 | 121/2 | 141/4 | 16 |
| Armrest height above the seat | 5½ | 6 | 7 | 81/4 | 8¾ |
| Armrest length | 61/2 | 71/2 | 81/2 | 9¾ | 11 |
| Max. working load (lb) | 100 | 120 | 175 | 220 | 250 |

2025 order form

Scan for sizing and pricing: https://www.rifton.com/compasschair



Use dimension chart to select appropriate size.

| | | R310 size 1 | | R320 size 2 | | R330 size 3 | | R340 size 4 | | R350 size 5 | |
|---------------------------------|-------------------------|-------------|---------|-------------|---------|-------------|---------|-------------|---------|-------------|---------|
| *Compass chair | | R311 | \$200 🗌 | R321 | \$230 🗌 | R331 | \$260 🗌 | R341 | \$290 🗌 | R351 | \$320 🗌 |
| *Leg type | Short | R314 | \$155 🗌 | N/A | | N/A | | N/A | | N/A | |
| CHOOSE | Short (low friction) | R334 | \$155 🗌 | N/A | | N/A | | N/A | | N/A | |
| | Standard | R315* | \$155 🗌 | R315 | \$155 |
| | Standard (low friction) | R335* | \$155 | R335 | \$155 🗌 | R335 | \$155 🗌 | R335 | \$155 🗌 | R335 | \$155 |
| New! Front stability | feet (pair) | R326 | \$40 🗌 |
| New! Rear stability feet (pair) | | R327 | \$40 🗆 | R327 | \$40 🗌 | R327 | \$40 🗌 | R327 | \$40 🗆 | R327 | \$40 🗌 |
| New! Dynamic feet (s | et of four) | R328 | \$100 🗆 | R328 | \$100 🗌 | R328 | \$100 🗌 | R328 | \$100 🗆 | R328 | \$100 🗌 |
| Seat belt | | R312 | \$48 🗌 | R312 | \$48 🗌 | R332 | \$48 🗌 | R342 | \$48 🗌 | R342 | \$48 🗌 |
| Pelvic harness | | R313 | \$180 🗌 | R323 | \$190 🗌 | R333 | \$200 🗌 | R343 | \$210 🗌 | R353 | \$220 🗌 |

^{*} Required

^{*} The standard legs can be used on size 1, but the lower two positions will not be accessible.

